

## Användarinstruktion & Säkerhetsföreskrifter

### User instruction & safety instruction

**Varugrupp:** FLEXXTRA slipskålar med PCD segment

**Product group:** FLEXXTRA PCD grinding cup



### Användarinstruktion (sv)

- Läs säkerhetsföreskrifterna för denna slipskål samt för arbetsplatsen du befinner dig på.
- Skålen monteras endast på axel anpassad för skålens hålbild, använd rätt dimensionerade insatsringar om så behövs.
- Använd lätt sliptryck, arbeta succesivt in i beläggningen och undvik överhettning av skål och maskin.
- Undvik i möjligaste mån att arbeta i materialet under beläggningen, detta för att undvika skador i segmenten
- Använd ett effektivt utsug för att undvika att slipmaterialet sätter sig fast i skålen samt för att skona maskinens livslängd.
- Vid kletande beläggningar krävs ofta även manuell rengöring av slipskål och maskin under arbetets gång, OBS stäng av maskin vid rengöring.
- Efter avslutat slipmoment lägg maskinen så att den ej vilar på skålen.

### Säkerhetsföreskrift (sv)

- Vid nyinköp samt vid återanvändande – kontrollera att inga uppkomna defekter såsom sprickor i segment eller stålkärna finns samt att skålen roterar fritt på maskinens axel.
- Se till att maskinen du ämnar använda är lämplig för denna slipskåls rekommenderade användningsområde.
- Läs maskinens manual beträffande handhavande, funktioner och varningar.
- Använd alltid skyddskläder, skyddsglasögon, skyddshandskar, hörselskydd och om så krävs andningsmask.
- Montering och användande av en defekt skål och/eller användande av en maskin som ej är lämpad för applikationen och/eller användande av en maskin ej passande för verktyget, kan skada verktyg/maskin eller orsaka allvarlig skada eller dödsfall.
- För ytterligare teknisk information vänligen kontakta din återförsäljare eller Flex Scandinavia AB.

## **User instruction (eng)**

- Pay attention to the safety instructions for this grinding cup and for your worksite.
- Assemble the cup only on a spindle with matching dimensions, use correctly dimensioned bushings if needed.
- Apply light load, work gradually into the coating, and avoid an overheated cup and tool.
- In order to spare the life of the segments, avoid as much as possible grinding into the underlying material.
- Use an effective dust extraction in order to avoid a clogged grinding cup and to spare the life span of the machine.
- When grinding sticky coatings often manually cleaning of cup and tool is as well needed during course of the work, NOTE: Shut the machine off when cleaning.
- Place the power tool after usage so it does not lean on the grinding cup.

-----

## **Safety instruction (eng)**

- At new purchase and reuse of tool always inspect the tool for cracks in segments or steel core and that the grinding cup rotates freely in the power tool.
- Please make sure that the power tool you are to assemble the tool into is suitable for the specification of the tool and its recommended usage.
- Please make sure that you have studied and understood the manual for the power tool and its instructions, safety requirements and warnings.
- Always use protection clothes, safety goggles, safety gloves, hearing protection and if needed dust mask.
- Assembly and usage of a damaged product and/or usage of the tool in a not appropriate work piece and/or usage of a power tool not suitable for the tool, may damage the tool/machine or cause serious injury or death.
- For further technical assistance, please contact your retailer or Flex Scandinavia AB.